

THE ORIGINAL NON-MOTORIZED TREADMILL

LIMITLESS PERFORMANCE - ZERO ELECTRICITY REQUIRED

Ideal for small group, speed development, and HIIT training for every fitness and skill level, the Curve is a non-motorized treadmill that allows a user to accelerate and decelerate with zero limitations on how fast, how long and how hard they train. The unique curved design of the treadmill allows a user to practice proper gait and running mechanics encouraging better posture while activating posterior chain muscles.

Sought after by professional sports teams and athletes around the world, the Curve treadmill delivers an unparalleled workout unlike any other treadmill. For any fitness level, the Curve is the universal treadmill for walkers, joggers, runners and sprinters.



For The Long Run®
WOODWAY®

WOODWAY WORLD HEADQUARTERS
W229 N591 Foster Court Waukesha, WI 53186
PHONE (800) 966 - 3929 | FAX (262) 522 - 6235
WOODWAY.COM

WOODWAY EUROPEAN HEADQUARTERS
Steinackerstr. 20, D-79576 Weil am Rhein, Germany
PHONE +49 - 7621 - 940 999 - 0 | FAX +49 - 7621 - 940 999 - 40
WOODWAY.DE

● Standard Feature

○ Optional Feature

| USER INTERFACE | CURVE | |
|----------------|--|--|
| | Coded/Non-Coded Polar Heart Rate Pick-up | ● |
| | USB Digital Speed Output | ○ |
| | USB Digital Speed Output with Curve Pro Software (Curve 1.5) | ○ |
| | RFID System | ○ |
| SPECIFICATIONS | LED Display Board | ● |
| | Running Surface Dimensions | 17" W x 67" L (43 x 170 cm) |
| | User Weight Capacity | Run: 400 lb. / Walk: 800 lb. (4 mph max) |
| | Belt Type | 60 Individual Slats |
| | Running Surface | 3/8" thick shock absorbing cushion |
| | Drive System | 112 Precision Ball Bearings with 12 Roller Guides (4 mm lateral tolerance) |
| | Unit Weight | 355 lb. (Shipping Weight 440 lb.) |
| | Width | 33" (84 cm) |
| | Length | 70" (178 cm) |
| | Height | 77" (196 cm) |
| | Self-propelled | ● |
| | Reverse | NA |
| | Power Supply | Not Required |
| | Warranty | 10 Year Frame & Belt 3 Year All Components 2 Year Battery Operated Display 1 Year Labor |

Treadmill specifications subject to change without written notice.
Warranties outside the U.S. may vary - Please contact your dealer for details.



| CURVE SERIES



CURVE TRAINER

This compact non-motorized treadmill is designed for walkers and joggers who are looking to build endurance and increase stamina. Train comfortably and for longer periods of time while reinforcing proper gait mechanics and posture.



CURVE

From beginners to serious athletes the Curve is the universal cardio solution. Users can workout at any speed with full control of the treadmill, making the Curve the ideal sport specific high intensity and small group training tool.



CURVE XL

Popular among Professional Sports teams and military training facilities the Curve XL features all the innovations and benefits of the standard Curve in an extra-large platform for the larger-lengthier athletes.



ECOMILL

The EcoMill does not require electricity but in fact transfers power utilizing the user's energy output. The display board is powered by a built in generator that is charged when a user walks or runs. Via the USB outlet, a user can also charge a mobile device.

The EcoMill also features an electromagnetic braking system to effectively control and maintain a consistent speed throughout. A user has the ability to set initial maximum speed at a 0.1 mph increment to prevent over-acceleration.

**FOR ADDITIONAL INFORMATION ABOUT THE FOLLOWING PRODUCT
VISIT WWW.WOODWAY.COM OR CALL 800.WOODWAY TO TALK TO A REPRESENTATIVE.**